



Coagulant Dosing

2024FA

We design and run experiments to study the floc dynamics occurring in the clarifier.

Github: https://github.com/AguaClara/coagulant_dose_response.git

Kayla Stephenson | ks929@cornell.edu Alex Gardocki | rag325@cornell.edu Christine Berlinger | cnb53@cornell.edu
Ulises Balbuena Figueroa | umb5@cornell.edu Anjali Asthagiri | aa2549@cornell.edu

Table of Contents

Background &
Introduction

Methods

Short Term &
Long Term Goals

Experimental
Setup

Current Work

Background & Introduction

Why Coagulant Dosing?

- Coagulant is a sticky substance that enables floc formation during flocculation and primary particle filtration during clarification.




Figure 1. AguaClara water treatment process

Background & Introduction

Why Automate Coagulant Dosing?

- Coagulant is manually dosed by full-time plant operators
 - Leads to high labor costs which presents a significant challenge for low-income communities.
- Automated dosing can increase access to drinking water treatment technology.

Background & Introduction

To automate coagulant dosing, a deeper understanding and physical model of particle dynamics during flocculation and clarification is required.

Flocculation Model

- Developed by Pennock et al. in 2018
- Describes aggregation of primary particles into flocs in the flocculator




Figure 2. Particle aggregation during flocculation

$$C_{flocculated} = \left(\frac{C_{coagulant}}{k_{pf} C_{influent}} + C_{influent}^{-2/3} \right)^{-3/2} \text{ where } k_{pf} = \frac{3}{2\pi k' G \theta} \left(\rho \frac{\pi}{6} \right)^{2/3}$$

To automate coagulant dosing, a **physical model** of clarification is required.

Background & Introduction




Figure 3. AguaClara clarifier




Figure 4. Floc sweeping in floc filter

Floc filter: slurry of suspended flocs in clarifier

Floc sweeping: removal of primary particles as they pass through flocs

Background & Introduction

Clarification Model: Spring 2024 and Summer 2024

$$C_{clarified} = C_{flocculated} e^{-k_c \frac{C_{coagulant}}{C_{influent}} (1 - P_{floc\ saturated})^{2/3} h_{floc\ blanket}} \text{ where } k_c = k' \beta \frac{\pi r_{floc}^2 C_{floc\ blanket}}{m_{floc}}$$

Background & Introduction

Clarification Model: Spring 2024 and Summer 2024

$$C_{clarified} = C_{flocculated} e^{-k_c \frac{C_{coagulant}}{C_{influent}} (1 - P_{floc\ saturated})^{2/3} h_{floc\ blanket}}$$

where $k_c = k'\beta \frac{\pi r_{floc}^2 C_{floc\ blanket}}{m_{floc}}$

Removal of primary particles by flocs in the floc filter




Figure 3. AguaClara clarifier




Figure 4. Floc sweeping in floc filter

Background & Introduction

Floc Saturation: the ratio of primary particles captured to the maximum number of particles a floc can capture

$$P_{floc\ saturated} = \frac{C_{flocculated} - C_{clarified}}{q(C_{influent} - C_{clarified})}$$




Figure 3. AguaClara clarifier




Figure 5. Floc saturation in floc filter

Background & Introduction

What is the current problem?

Clarification constant K_c - fitted value (~ 60) and theoretical value (~ 0.06) do not match. Model underperforms clarification.

What is missing?

Model assumes a well-mixed floc filter with constant concentration and steady-state floc saturation. Does not fully account for temporal or spatial variation in floc filter concentration and floc saturation.




Figure 6. Significant difference between fitted and theoretical predictions of clarifier performance

Background & Introduction

Floc saturation spatial variation - Hypotheses




Figure 7. Spatial distribution of flocs in clarifier

Experimental Setup

Research objectives:

1. Determine the spatial distribution of concentration and floc saturation in the floc filter
2. Correlate floc filter state with primary particle removal performance
3. Analyze how the above change temporally due to fluctuating influent turbidity and coagulant dose conditions


Experimental apparatus criteria:

- ☐ Short residence time
- ☐ Small, benchtop scale
- ☐ Modular, disassemblable
- ☐ Ability to measure floc filter concentration and floc saturation in situations.

Methods

Miniature Clarifier

Short residence time (<5 min), benchtop-scale
Acrylic, glass, metal, tubing, rubber; laser cut
First iteration: not modular



All measurements in mm and degrees




Figure 8. Miniature clarifier design and dimensions

Methods

Visualization

Hurst et al., 2013

- Floc filter concentration and growth rate

Stream of colored primary particles

- Spatial variation in floc saturation

Reflected light (frontlit)




Figure 9. Experimental apparatus for imaging floc filter




Figure 10. Imaging floc filter concentration (Hurst et al., 2013)

Current Work

Jar Test - Experimental Design

1. Formed colored primary particles with rose kaolin clay
2. Formed flocs with white kaolin clay and coagulant
3. Divided primary particles into control and experimental
4. Added flocs to experimental to simulate floc sweeping in clarifier
5. Evaluated color after allowing flocs to settle

Conclusion: Rose kaolin primary particles are visibly dyed, but further testing needed to confirm dying of flocs



Figure 11. Colored Primary Particles After Floc Sweeping



Figure 12. Colored Primary Particles (Frontlit)



Figure 13. Colored Primary Particles (Backlit)

Broader Applications

- Exploring novel approach to visualize floc saturation
- Creating an easy-to-build and modular mini-clarifier to help future research
- Developing novel physical model of floc filter-based clarification
 - Understanding of floc filter dynamics → improved control over the state of the floc filter → more widespread use of floc filter-based treatment processes
 - Inform new clarifier designs

Short Term Goals

- Purchase materials and build miniature clarifier
- Conduct experiments with miniature clarifier apparatus and interpret results
- Run more trials with colored primary particles
 - Red-40 dye
 - Reactive red & reactive yellow dye
 - Fluorescent latex beads

Long Term Goals

- Make the clarifier design more modular
- Improve the clarification model based on our results
- Move floc waste tube based on spatial distribution conclusions
- Apply findings to inform the work of the Plantita Subteam and Versawater
- Complete EPA P3 grant proposal

References

1. *AguaClara Hydraulic Flocculation Model*. AguaClara Hydraulic Flocculation Model - AguaClara v1.4.35 documentation. (n.d.).
https://aguaclara.github.io/Textbook/Flocculation/Floc_Model.html
2. *Clarification introduction*. Clarification Introduction - AguaClara v1.4.35 documentation. (n.d.).
https://aguaclara.github.io/Textbook/Clarification/Clarifier_Intro.html
3. *Coagulant Automation*. Coagulant Automation - AguaClara v1.4.35 documentation. (n.d.).
https://aguaclara.github.io/Textbook/Operation/Coagulant_Automation.html
4. Head, R., Hart, J., & Graham, N. (1997). Simulating the effect of blanket characteristics on the floc blanket clarification process. *Water Science and Technology*, 36(4).
[https://doi.org/10.1016/s0273-1223\(97\)00422-8](https://doi.org/10.1016/s0273-1223(97)00422-8).
5. Hurst, M., Weber-Shirk, M., & Lion, L. W. (2014). Image analysis of floc blanket dynamics: Investigation of floc blanket thickening, growth, and Steady State. *Journal of Environmental Engineering*, 140(4). [https://doi.org/10.1061/\(asce\)ee.1943-7870.0000817](https://doi.org/10.1061/(asce)ee.1943-7870.0000817).
6. Hurst, M., Weber-Shirk, M., Charles P., & Lion, L. W. (2013). Apparatus for Observation and Analysis of Floc Blanket Formation and Performance. *Journal of Environmental Engineering*, 140(1). [https://doi.org/10.1061/\(ASCE\)EE.1943-7870.0000773](https://doi.org/10.1061/(ASCE)EE.1943-7870.0000773).

Thank You!

Questions?

Kayla Stephenson //
ks929@cornell.edu

Christine Berlinger //
cnb53@cornell.edu

Alex Gardocki //
rag325@cornell.edu

Anjali Asthagiri //
aa2549@cornell.edu

Ulises Balbuena Figueroa //
umb5@cornell.edu